



+33 1 30 34 76 76

Moulin de verville, 95760  
Valmondois, France

PREVOR



### Advantages

- - Easily identified
- - Easily transportable
- - Easy to use
- - Ready to use.
- - Allows quick action without assistance
- - Box suitable for washing the whole body thanks to the different packaging included
- - Which packaging for which surface?

LPMD Eye Wash (500 mL package)

Wash one hand, one face MINI DAP Spray (200 mL package)

Whole body wash Portable Autonomous Shower DAP (5 L package)

- - Gentle, pressureless, self-contained wash with all containers (eye wash, aerosol and shower).
- - Sterile solution.
- - Washing control: the total and unique use of each container makes it easy to know the washing time.
- - Modular installation. Wall-mounted or wheeled box
- - Waterproof case (IP54), meets industrial hygiene and cleanliness requirements.
- - Protects the products from dust and corrosion
- - No special maintenance
- - The wall-mounted washing station is independent and therefore easy to move for workshops with a modular character.
- - Conforms to EN 15154-4 and DIN EN 15154-4 standards
- - CE conformity



# Technical data sheet

## Coffret intégral de solution Diphotérine® - station complète ou coffret roulettes - DAPBOX PPE



### Characteristics

<b>Supplier</b>	Société PREVOR Moulin de Verville 95760 Valmondois (33) 01-30-34-76-76
<b>Sizes</b>	725 mm high 380 mm wide 322 mm deep
<b>Capacity</b>	2 LPMD Eye Washes (500 mL package) 1 eye wash of AfterwashII® solution (200 mL package) 1 MINI spray (200 mL package) 1 portable self-contained shower (5 L package) 1 optional MINI spray (200 mL package) 1 bucket of optional Trivorex® neutralizing absorbent (10 kg pack)
<b>Shelf-life</b>	2 years
<b>Content</b>	DIPHOTERINE® solution, AFTERWASHII® solution. Optional: Trivorex® Neutralizing Absorbent
<b>Use</b>	Emergency washing of eye or skin splashes of chemicals Up to two eyes, a face (eye wash and spray) and a whole body (portable self-contained shower)
<b>Delay to interfere</b>	In the first minute